

NASA Technical Memorandum 4636

1N-35
2-19-44
21

Current Loop Signal Conditioning: Practical Applications

Karl F. Anderson

January 1995



(NASA-TM-4636) CURRENT LOOP SIGNAL
CONDITIONING: PRACTICAL
APPLICATIONS (NASA, Dryden Flight
Research Center) 22 p

N95-18735

Unclas

H1/35 0037964

Current Loop Signal Conditioning: Practical Applications

Karl F. Anderson
*Dryden Flight Research Center
Edwards, California*



National Aeronautics and
Space Administration
Office of Management
Scientific and Technical
Information Program
1995

CURRENT LOOP SIGNAL CONDITIONING: PRACTICAL APPLICATIONS

Karl F. Anderson
Measurement Systems Engineer
NASA Dryden Flight Research Center
Edwards, California

ABSTRACT

This paper describes a variety of practical application circuits based on the current loop signal conditioning paradigm. Equations defining the circuit response are also provided. The constant current loop is a fundamental signal conditioning circuit concept that can be implemented in a variety of configurations for resistance-based transducers, such as strain gages and resistance temperature detectors. The circuit features signal conditioning outputs which are unaffected by extremely large variations in lead wire resistance, direct current frequency response, and inherent linearity with respect to resistance change. Sensitivity of this circuit is double that of a Wheatstone bridge circuit. Electrical output is zero for resistance change equals zero. The same excitation and output sense wires can serve multiple transducers. More application arrangements are possible with constant current loop signal conditioning than with the Wheatstone bridge.

INTRODUCTION

The Wheatstone bridge circuit has a long history of successfully being used to measure electrical resistance and small changes in that resistance.¹ The variable resistance strain gage has used the Wheatstone bridge circuit in various forms for signal conditioning since its inception.² An adaptation of the Wheatstone bridge includes multiple constant current excitation sources within and external to the bridge.³ A similar technique for minimizing the number of lead wires in multi-channel strain measurements also exists.⁴

Current loop topology was developed to overcome the inherent difficulties of the Wheatstone bridge without the complexity arising from multiple excitation sources.⁵ An extension of this paradigm provides the ability to simultaneously measure temperature and strain by using thermocouple wire to connect a variable-resistance strain gage to the signal conditioning circuitry.⁶ The current loop is in daily use for strain gage signal conditioning at the NASA Dryden Flight Research Center.

This paper reviews the theory of the current loop paradigm and presents various possibilities for accomplishing the key voltage difference measurement function. Two loop current-regulation approaches are presented. In addition, a variety of circuit applications based on the current loop signal conditioning paradigm is described. Equations defining the circuit response are presented.

Key contributions of Allen R. Parker, Jr., who implemented the equations of the constant loop signal conditioning concept with practical circuitry and software, are gratefully acknowledged.

CURRENT LOOP THEORY

The current loop paradigm is a fundamental circuit concept that will operate with various electrical components and forms of excitation. Excitation possibilities include direct, alternating, and pulsed currents. Inductance and capacitance measurements are possible with alternating current excitation. The various forms of excitation each have advantages that indicate their selection for use in certain applications and environments. For simplicity, direct current excitation and resistive components are used in the illustrations and equations presented in this paper.

Single Remote Gage Resistance

Figure 1 diagrams the current loop signal conditioning paradigm and illustrates the theory that explains its operation for a single-gage resistance sensor. The unique part of the approach illustrated in figure 1 is the four-terminal voltage difference measuring system. The R_{w1} through R_{w4} are lead wire resistances with R_{w1} and R_{w2} carrying the constant excitation current, I . The gage is modeled by an initial resistance, R , in series with its resistance change, ΔR . Note that if the sensing system for the voltage across the gage, V_g , has a sufficiently high input impedance, then




Figure 1. Current loop circuit for single-gage resistance.

no appreciable current will flow through R_{w3} and R_{w4} . As a result, no significant voltage drop will occur across them. The R_{ref} is a reference resistor used to develop a voltage, V_{ref} , which is subtracted from the voltage across the gage, V_g .

The four-terminal, high-impedance voltage difference measuring system of figure 1 uses two terminals to sense V_g and two terminals to sense V_{ref} . Equations 1 through 3 model the circuit and illustrate the benefit of this four-terminal voltage measurement in a single constant current loop.

$$V_{out} = V_g - V_{ref} \quad (1)$$

$$V_{out} = I(R + \Delta R) - I(R_{ref}) \quad (2)$$

When $R_{ref} = R$,

$$V_{out} = I(\Delta R) \quad (3)$$

Note that R_w does not appear in equations 1 through 3; therefore, V_{out} is theoretically uninfluenced by any R_w .

A small difference between the initial gage resistance and the reference resistor will result in a correspondingly small output offset. This offset can be subtracted out in data reduction. This practice is standard procedure in strain-gage data reduction. Such subtraction is also commonly used with practical Wheatstone bridge circuits. The maximum output voltage change per unit of resistance change is achieved when using constant current excitation. Ignoring the second-order effects of the ΔR term in the denominator of the equation for the Wheatstone bridge output gives

$$e_o = (E_x / 4)(\Delta R / R) \quad (4)$$

where e_o is the output, and E_x is the excitation for Wheatstone bridge circuits. Because the E_x is $2V_g$ in a Wheatstone bridge circuit, the output in terms of the gage current and gage resistance change is

$$e_o = I(\Delta R) / 2 \quad (5)$$

Note that the output available from the Wheatstone bridge is one-half of the output available from the constant current loop output (eq. 3).

Multiple Remote Resistances

The same reference resistor voltage drop, V_{ref} , can be used as an input for more than one voltage difference function. This feature makes it practical to include more than one gage resistance in a single current loop. The key benefit of including multiple gages in the current loop is a reduction in the required number of lead wires.⁵ To make apparent strain corrections, the reference resistance can be a gage resistance to achieve temperature compensation and arithmetic calculations. Refer to the Apparent Strain Corrections sub-subsection for additional details.

Figure 2 illustrates three gage resistances, R_{g1} , R_{g2} , and R_{g3} , in a single loop. This configuration is applicable to the common technique of using a group of three strain gages installed near each other to estimate the magnitude and direction of principal strain. The advantages of the constant current loop are obtained with only six lead wires. That is three wires less than are required when using a Wheatstone bridge circuit for the same measurement requirement.




Figure 2. Strain-gage rosette measurement using current loop signal conditioning with six lead wires.

RATIOMETRIC CURRENT LOOP MEASUREMENTS

A single reference voltage used to derive system voltage reference levels can simplify and stabilize the measurement system. Figure 3 illustrates the ratiometric current loop which uses V_{ref} to normalize the output voltage V_{out} . If the loop current should vary, then V_{ref} will vary by the same amount. The resulting data values are the same regardless of the level of excitation current as long as no appreciable current variation occurs during the analog-to-digital conversion process. With ratiometric measurements,

$$\text{Data} = V_{out} / V_{ref} \quad (6)$$

$$\text{Data} = I\Delta R/IR_{ref} \quad (7)$$

When $R_{ref} = R$,

$$\text{Data} = \Delta R/R \quad (8)$$

independent of I . For this reason, ratiometric voltage measurements make excitation regulation theoretically unnecessary.




Figure 3. Current loop system with ratiometric output.

Practical ratiometric current loop voltage measurements can be accomplished in at least two ways. The V_{ref} can be used as the reference input to the system analog-to-digital converter to achieve ratiometric current loop measurements. Alternatively, the measurement of V_{out} can be numerically divided by a high-resolution measurement of V_{ref} taken at essentially the same excitation current I during which V_{out} was measured.

In practice, the noise floor of the data varies with excitation level. Lower excitation levels necessarily result in a lower signal-to-noise ratio. If, however, excitation is maintained at a reasonable level, then the data output will be at least as precise and accurate from ratiometric measurements as with carefully regulated excitation. Current loop signal conditioning can be designed to operate without the expense of regulation circuitry over the useful life of a battery power supply.

For simplicity, the equations developed later in this paper assume constant current regulation. Those equations adapt directly to ratiometric measurements to yield the same data result with unregulated excitation.

VOLTAGE DIFFERENCE MEASUREMENT

The key function that makes possible the current loop paradigm is four-terminal voltage difference measurement. This measurement can be accomplished in many ways. The objective is to develop an output that is in direct proportion to the difference between two electrical potential differences. The resulting output must have appropriate stability and resolution for the intended application. Strain gage signal conditioning requires stability and resolution to within a few microvolts.

Several fundamental possibilities have been identified for accomplishing voltage difference measurement and are described in the following subsections. These possibilities develop a single potential difference output which is then observed with a conventional two-input voltmeter having suitable precision and stability. Other possibilities may also exist.

Potential Transport

A first potential difference can be transported from an inconvenient environment to another circuit location where it can be conveniently observed. This approach has found use in the “flying capacitor” multiplexer circuit.

Figure 4 shows a flying-capacitor-based current loop circuit which uses this approach. In the development of the current loop concept, potential transport was the first approach identified which





Figure 4. The flying capacitor circuit for developing a voltage difference measurement.

Current Transport

Data current circuit

Figure 5 shows a current loop circuit using a data-current-based voltage difference measuring circuit. Here, the voltage developed across R_{d1} is caused to equal V_g by the operational amplifiers OA1 and OA2 and the current regulator pass element, Q1. This operation develops data current



$$ID = V_g / R_{d1} \quad (9)$$

Amplifier OA1 is connected to cause the voltage sensed through R_{w3} to appear at the top end of R_{d1} . The input of OA2 causes the voltage sensed through R_{w4} to appear at the bottom end of R_{d1} by turning on Q1 to cause the voltage drop across R_{d1} to equal V_g . The R_h provides a loop voltage drop to allow enough “headroom” to permit Q1, the data current pass element, to operate unsaturated.

The voltage drop across R_{d2} is equal to V_g when R_{d2} is equal to R_{d1} . The V_{out} is then the desired voltage difference between V_g and V_{ref} . Amplification is available in this circuit when R_{ref} and R_{d2} are proportionally greater than R and R_{d1} . The output of this circuit is

$$K = R_{ref} / R = R_{d2} / R_{d1} \quad (10)$$

$$V_{out} = KV_g - V_{ref} \quad (11)$$

$$V_{out} = KI\Delta R \quad (12)$$

Current-summing amplifier circuits

Operational amplifiers connected to perform precision analog arithmetic can develop an output proportional to the difference in two input potential differences. The following sub-subsections use a summing amplifier and an instrumentation amplifier as examples to illustrate these possibilities.

Summing amplifiers. Figure 6 illustrates a classic analog subtraction circuit. This circuit uses operational amplifiers in a summing configuration to develop an output proportional to the voltage difference between two sets of floating inputs. Amplifiers OA1 through OA4 act as buffers to present a high impedance at their four inputs to the circuit nodes where the two voltage drops, V_g and V_{ref} , are sensed. Amplifier OA4 is unnecessary when its input is from a low-impedance point, such as a power supply output. Input summing resistances, R_i , and gain-setting resistances, R_o , are each matched resistance sets. If the R_i resistors were directly connected to V_g and V_{ref} , then significant currents could be diverted from the current loop to the voltage difference measuring system, hence the need for buffer amplifiers OA1 through OA4. Absence of buffer amplifiers could cause the output to be unacceptably influenced by R_{w1} through R_{w4} . Amplification is available in this circuit in proportion to R_o / R_i . The output of this circuit is

$$V_{out} = (V_g - V_{ref})(R_o / R_i) \quad (13)$$

$$V_{out} = I\Delta R(R_o / R_i) \quad (14)$$

Instrumentation amplifiers. Figure 7 illustrates subtraction by means of an instrumentation amplifier circuit. When operating at unity gain, an instrumentation amplifier produces an output voltage equal to the voltage difference between its input terminals. This output voltage is developed with respect to the point at which the output sense terminal is connected. By this means, the input level can be replicated at another point in the circuit to appear in series opposition to a second voltage. By connecting the sense terminal to the bottom of the reference resistor, the voltage between the instrumentation amplifier output and the most positive end of reference resistor




Figure 6. Operational amplifier circuit for developing a voltage difference measurement.

is $V_g - V_{ref}$, the desired voltage difference output. Gain is also available in this circuit when the instrument amplifier gain is adjusted to equal R_{ref}/R . The INA114 instrumentation amplifier is an appropriate choice for this purpose because of its low output-referenced errors.

CALIBRATION APPROACHES

A means for calibrating the overall measuring system end-to-end with respect to input resistance changes is a desirable operational feature. Fortunately, there is no need to parallel a remote R_g to achieve a useful calibration for sensitivity to individual loop resistance changes because current is the same in all parts of the loop. The circuitry carrying loop current is indicated by heavy lines in figures 1 through 15. If the desired output is the difference between two remote resistance changes, then paralleling one of these resistances may be necessary for a useful calibration. Calibration by changing the reference voltage and gage current are described next.

Changing Reference Voltage

Figures 1, 2, 4, 5, 6, and 7 show a calibration circuit that changes the reference voltage by a predictable amount, ΔV_{cal} . This circuit consists of a calibration resistor, R_{cal} , which is electrically paralleled with the reference resistor, R_{ref} , while the calibration switch is closed. This connection reduces the apparent resistance of R_{ref} by ΔR_{cal} as calculated from

$$\Delta R_{cal} = R_{ref} - (R_{ref})(R_{cal})/(R_{ref} + R_{cal}) \quad (15)$$




Figure 7. Instrumentation amplifier circuit for developing a voltage difference measurement.

The mechanical strain simulated by a ΔV calibration is

$$\text{Strain} = \Delta R_{cal} / (GF R_g) = R_{ref}^2 / [GF R_g (R_{ref} + R_{cal})] \quad (16)$$


For convenience in reducing strain gage data when $R_g = R_{ref}$,

$$\text{Strain} = R_{ref} / GF (R_{ref} + R_{cal}) \quad (17)$$

Because the same current, I , flows in all parts of the current loop, an apparent reduction ΔR_{cal} in R_{ref} appears in the system output as a voltage change, ΔV_{cal} , as though there had been an equivalent increase, ΔR_{cal} , in R_g . Thus, R_{cal} , R_g , and R_{ref} define a reliable overall measurement system sensitivity factor when a change in system output is caused by paralleling R_{ref} with R_{cal} .

Changing Gage Current

Several new opportunities for circuit features develop when the voltage V_{ref} across R_{ref} is controlled to be constant in the feedback loop which regulates excitation current. As an example, figure 8 illustrates the change in excitation current, ΔI_{cal} , calibration technique.



940029

Figure 8. Current loop circuit with ΔI calibration.

The constant current regulator operates by forcing sufficient current through the loop to cause the voltage drop across R_{ref} to equal the reference source. This operation maintains the loop current at

$$I = V_{ref}/R_{ref} \quad (18)$$

Connecting R_{cal} in parallel with R_{ref} causes a calibration current increment, ΔI_{cal} , to additionally flow in the constant current loop.

$$\Delta I_{cal} = V_{ref}/R_{cal} \quad (19)$$

The output indication ΔV_{cal} is a function of the gage resistance R_g and ΔI_{cal} . Note that from the voltage difference measuring system perspective, ΔV_{cal} could have been developed by either a change in gage resistance, ΔR_{cal} , or by a change in excitation current, ΔI_{cal} . Equation 20 defines this equivalence.

$$\Delta V_{cal} = \Delta I_{cal} R_g = I \Delta R_{cal} \quad (20)$$

Substitution shows that

$$\Delta R_{cal}/R_g = R_{ref}/R_{cal} \quad (21)$$

Note that the denominator of equation 21, which models the current change calibration, does not include R_g as does equation 16 for voltage change calibration. By definition, strain is developed from resistance measurements by means of a gage factor, GF , calibration. That is,

$$GF(\text{strain}) = \Delta R/R \quad (22)$$

As a result, the strain simulated by a ΔI calibration is

$$\text{Strain} = R_{ref}/(GF R_{cal}) \quad (23)$$

This result is interesting in that the data shift caused by paralleling R_{ref} with R_{cal} provides the system sensitivity to $\Delta R/R$ *without prior knowledge of R_g* .

Note that ΔI calibration involves precise currents flowing through R_{ref} and R_g . A small systematic error can exist when a ΔI offset adjustment circuit is also in use. This error is typically ignored, but it is simple to remove at the “balance” condition (zero electrical output from the voltage difference measuring system). In this situation, the magnitude of R_g instead R_{ref} in equation 21 is used.

OFFSET ADJUSTMENTS

Offset adjustments should be derived from the excitation current level. This derivation will cause excitation level variations to result in percent-of-reading sensitivity errors rather than in additional percent-of-full-scale offset drifts. Offset adjustment by changing the reference voltage and by changing the gage current are described next.

Changing Gage Current

Figure 9 illustrates a ΔI offset adjustment circuit. Magnitude of the offset adjustment is limited by R_{offset} . Resistor R_{offset} is connected between the positive end of V_{ref} and a potential V_{offset} , with a magnitude and polarity adjustable between zero and $2V_{ref}$. This circuit provides a variable bipolar offset current, $\pm I_{offset}$, which increases or decreases I_g .

$$\pm I_{offset} = \pm V_{offset} / R_{offset} \quad (24)$$

The offset current is applied additively to the gage current, I_{gage} , to cause the gage voltage, V_g , to approach V_{ref} , the voltage drop across the reference resistor.

$$V_g = (I_{ref} + I_{offset})R_g \quad (25)$$

Changing Reference Voltage

Figure 10 illustrates a ΔV offset adjustment circuit with ΔI calibration. The offset level is applied additively to the reference voltage before it is sensed by the voltage difference measuring system. This approach does not affect the level of calibration output from shunting R_{ref} with R_{cal} . Offset authority is established by the ratio of output-to-input offset amplification resistances, R_{oo} to R_{io} .




Figure 9. Current loop circuit with ΔI offset adjustment.




Figure 10. Current loop circuit with reference voltage offset adjustment.

APPLICATIONS

Examples shown in figures 1 through 10 sense the voltage drop, V_g , directly across a gage resistance. This connection causes the output of current loop signal conditioning to be uninfluenced by any lead wire resistance as long as the voltage difference measurement system and the current regulator operate within their ability to reject common mode voltages and to deliver a constant current to the set of resistances in the loop.

In addition, these figures provide separate outputs for each gage resistance in the current loop. Arranging two or more gages in a current loop circuit such that gage resistance changes add, subtract, or both, to develop a single output can be useful. Half- and full-bridge arrangements of the Wheatstone circuit combine gage outputs in this manner.² Current loop signal conditioning provides more analog computation opportunities than the Wheatstone bridge. The application examples that follow show how additional computations can be accomplished.

Minimizing Conductor Quantity

If lead wire resistances are consistent enough, then acceptable results may be obtained by using fewer lead wires. Three-wire connections to one-fourth- and one-half-bridge Wheatstone bridge circuits always depend on consistent lead wire resistance.²

Three-wire connection of gage resistances in a current loop is accomplished by including a lead wire resistance with each monitored resistance (R_{w1} with R_g and R_{w2} with R_{ref}) (fig. 11). As long as R_{w1} and R_{w2} remain identical, they can vary without their changes being observed. All other benefits of current loop signal conditioning remain available in this situation.

Equations 26 and 27 describe three-wire gage connections.

$$V_{out} = I [(R + \Delta R + R_{w1}) - (R_{ref} + R_{w2})] \quad (26)$$


When $R_{w1} = R_{w2}$ and $R_{ref} = R$,

$$V_{out} = I (\Delta R) \quad (27)$$

This result is the same as in equation 2. Lead wires with resistances that vary identically will induce no more than a constant offset in the output indication.

Using Analog Computations

Analog computations are possible in current loop circuits by including the voltage drops of additive gages in the direct (V_g) input and the voltage drops of subtractive gages in the inverting (V_{ref}) input of a voltage difference measurement circuit. In this situation, calibration by shunting a remote resistance in the circuit may be necessary. Shunting remote gage resistances through their sense lead wires is necessary because no "local" reference resistance is sensed by the voltage difference measuring circuit. Single and multiple loop computations are discussed in the following sub-subsections.



940032

Figure 11. Three-wire connection to a gage.

Single loop

A variety of analog computations can be implemented within a single loop. These computations are accomplished by using one or more remote gages in a current loop to develop V_g , V_{ref} , or both. Note also that V_g for one voltage difference measuring circuit can be used as V_{ref} for another circuit. This feature makes the constant current loop an extremely versatile circuit for analog computations based on changes in remote gage resistances.

Apparent strain corrections. These corrections are accomplished by developing V_{ref} from the voltage drop across an “unstrained” gage in the same temperature environment as one or more strain-sensing gages. Figure 12 shows how apparent strain corrections are done without developing errors from lead wire resistances. Here, shunting R_{cal} across the remote unstrained gage provides a simultaneous calibration output for each of the strain-sensing voltage difference measuring systems.

Unlike the Wheatstone bridge, a single unstrained gage in a current loop can provide temperature compensation for several independent strain-sensing gages, for example, a strain gage rosette. This circuit minimizes gage and lead wire quantity in a circuit that is insensitive to lead wire resistance changes. If wire resistances R_{w1} and R_{w2} remain alike, then only three lead wires may be required.




Figure 12. Temperature compensation using an unstrained gage for the reference resistance.

Wheatstone bridge computation similarities. Figure 13 illustrates how a set of four gages can be connected in a current loop such that their resistance changes add and subtract in a manner similar to Wheatstone bridge circuits.² Two gages comprise the additive and two gages comprise the subtractive voltage-sensing segments of the current loop. Note that any number of gages could have been included to expand the analog computation equation. When each gage has the same initial resistance, the output from this circuit is

$$V_{out} = I(\Delta R_{g1} + \Delta R_{g2} - \Delta R_{g3} - \Delta R_{g4}) \quad (28)$$

Gage resistance labels in figure 13 do not reflect the adjacent positions they would have in a four-arm Wheatstone bridge arrangement. Resistance changes in opposite Wheatstone bridge arms are additive; such changes in adjacent arms subtract.² If R_{w1} and R_{w2} are sufficiently alike, then the current loop equivalent of the Wheatstone bridge can be achieved with only three lead wires.

Multiple loops

Figure 14 illustrates how multiple current loop channel outputs can be combined to achieve a single output that is independently influenced by each current loop. This circuit accomplishes the calculations for combining measurement channels to implement loads equations.⁷ The output from this circuit is

$$V_{out} = RF(V1/RI1 + V2/RI2 + V3/RI3 - V4/RI4 - V5/RI6 - V6/RI6) \quad (29)$$




Figure 13. Analog computation using four gages.




Figure 14. Multiple loop computation circuit.

Modifying Existing Wheatstone Bridge Systems

A substantial capital investment already exists in measurement systems that use Wheatstone bridge-based signal conditioning. Converting these existing systems to current loop operation is possible and practical.

Figure 15 shows a NASA-designed circuit modification to the existing Dryden Flight Research Center, Thermostructural Laboratory, Edwards, California, data acquisition system. This modification converts the signal conditioning from Wheatstone bridge to current loop by replacing the Wheatstone bridge completion and calibration circuitry. No other hardware or software changes were required to include current loop signal conditioning.

Several hundred channels of this circuit are now in daily operational use. All component values are identified. The designated INA114 instrumentation amplifier component is critical. The three operational amplifiers which it contains are essentially identical. As a result, this component has exceptionally low output-referred errors.




Figure 15. Modification to convert existing equipment from Wheatstone bridge to current loop circuitry.

CONCLUSIONS

The constant current loop is a fundamental signal conditioning circuit concept that can be implemented in a variety of configurations. Current loop signal conditioning circuits can be insensitive

to changes in the resistance of any lead wire. The current change calibration identifies sensitivity to strain by developing an output that is directly proportional to the gage resistance at the time of calibration. Adapting existing Wheatstone bridge-based measurement systems to current loop operation can be practical. More application arrangements are possible using the constant current loop than using the Wheatstone bridge.

REFERENCES

¹Wheatstone, Charles, "An Account of Several New Instruments and Processes for Determining the Constants of a Voltaic Circuit," *Philosophical Transactions of the Royal Society of London*, vol. 133, 1843, pp. 303–329.

²Perry, C.C. and H.R. Lissner, *The Strain Gage Primer*, McGraw-Hill, Inc., New York, 1962.

³Weeks, Barret B. and William E. Shoemaker, "Tri-Current Transducer Conditioner," ISA pre-print no. 9.1-3-65, 1965.

⁴Penharlow, David, "The Use of Strain Gage Transducers With Dual Constant Current Excitation," Application note 8702, Aydin Vector Division, Newton Industrial Commons, Newton, Pennsylvania, undated.

⁵Anderson, Karl F., *The Constant Current Loop: A New Paradigm for Resistance Signal Conditioning*, NASA TM-104260, 1992.

⁶Parker, Allen R., Jr., *Simultaneous Measurement of Temperature and Strain Using Four Connecting Wires*, NASA TM-104271, 1993.

⁷Skopinski, T.H., William S. Aiken, Jr., and Wilbur B. Huston, *Calibration of Strain-Gage Installations in Aircraft Structures for the Measurement of Flight Loads*, NACA-1178, 1954.

REPORT DOCUMENTATION PAGEForm Approved
OMB No. 0704-0188

Public reporting burden for this collection of information is estimated to average 1 hour per response, including the time for reviewing instructions, searching existing data sources, gathering and maintaining the data needed, and completing and reviewing the collection of information. Send comments regarding this burden estimate or any other aspect of this collection of information, including suggestions for reducing this burden, to Washington Headquarters Services, Directorate for Information Operations and Reports, 1215 Jefferson Davis Highway, Suite 1204, Arlington, VA 22202-4302, and to the Office of Management and Budget, Paperwork Reduction Project (0704-0188), Washington, DC 20503.

1. AGENCY USE ONLY (Leave blank)		2. REPORT DATE January 1995	3. REPORT TYPE AND DATES COVERED Technical Memorandum	
4. TITLE AND SUBTITLE Current Loop Signal Conditioning: Practical Applications			5. FUNDING NUMBERS WU 505-63-50	
6. AUTHOR(S) Karl F. Anderson				
7. PERFORMING ORGANIZATION NAME(S) AND ADDRESS(ES) NASA Dryden Flight Research Center P.O. Box 273 Edwards, California 93523-0273			8. PERFORMING ORGANIZATION REPORT NUMBER H-2026	
9. SPONSORING/MONITORING AGENCY NAME(S) AND ADDRESS(ES) National Aeronautics and Space Administration Washington, DC 20546-0001			10. SPONSORING/MONITORING AGENCY REPORT NUMBER NASA TM-4636	
11. SUPPLEMENTARY NOTES Presented at the 1995 Measurement Science Conference, Anaheim, California, January 26-27, 1995.				
12a. DISTRIBUTION/AVAILABILITY STATEMENT Unclassified—Unlimited Subject Category 35			12b. DISTRIBUTION CODE	
13. ABSTRACT (Maximum 200 words) This paper describes a variety of practical application circuits based on the current loop signal conditioning paradigm. Equations defining the circuit response are also provided. The constant current loop is a fundamental signal conditioning circuit concept that can be implemented in a variety of configurations for resistance-based transducers, such as strain gages and resistance temperature detectors. The circuit features signal conditioning outputs which are unaffected by extremely large variations in lead wire resistance, direct current frequency response, and inherent linearity with respect to resistance change. Sensitivity of this circuit is double that of a Wheatstone bridge circuit. Electrical output is zero for resistance change equals zero. The same excitation and output sense wires can serve multiple transducers. More application arrangements are possible with constant current loop signal conditioning than with the Wheatstone bridge.				
14. SUBJECT TERMS Bridge circuits; Circuit theory; Electrical engineering; Electronic circuits; Electronic test equipment; Electronics; Gages; Instrumentation; Measuring instruments; Remote sensors; Resistance temperature detectors; Resistors; Sensors; Strain gage instruments; Structural testing; Test facility instruments; Testing of materials; Transducers			15. NUMBER OF PAGES 23	
			16. PRICE CODE AO3	
17. SECURITY CLASSIFICATION OF REPORT Unclassified	18. SECURITY CLASSIFICATION OF THIS PAGE Unclassified	19. SECURITY CLASSIFICATION OF ABSTRACT Unclassified	20. LIMITATION OF ABSTRACT Unlimited	